



# CHALMERS

EDA222 Real time systems

## Laboratory assignments:

### CONTROL AND MONITORING A MODEL RAILROAD


#### Contents:

<b>1</b>	<b>INTRODUCTION.....</b>	<b>2</b>
1.1	Purpose	2
1.2	Train simulator overview	2
1.3	Train simulator commands	3
1.4	Train simulator messages	4
1.5	Train simulator configurations	5
<b>2</b>	<b>COMMUNICATING WITH THE SIMULATOR.....</b>	<b>7</b>
2.1	Control and status registers	7
2.2	Sending commands to the simulator	7
2.3	Receiving messages from the simulator.	7
2.4	Control computer memory space	8
<b>3</b>	<b>ASSIGNMENT 1 .....</b>	<b>9</b>
3.1	Resource handler	9
<b>4</b>	<b>ASSIGNMENT 2 .....</b>	<b>10</b>
4.1	Testing commands to the simulator	10
4.2	Monitoring messages from the simulator	11
<b>5</b>	<b>THE FINAL ASSIGNMENT.....</b>	<b>11</b>
5.1	Requirements on the program	11
5.2	Practical hints	11
<b>6</b>	<b>CRITERIAS TO PASS .....</b>	<b>12</b>
6.1	Reporting and documentation	12
6.2	Instructions for report writing	12

# 1 Introduction

## 1.1 Purpose

The purpose with this laboratory assignment is to give a practical example of real time and machine oriented programming. Our example is a model railroad where two trains can be moving at the same time and independent of each other. The model railroad looks as follows:



**Figure 1: Final lab assignment simulator configuration**

Along the track there are exchanges and a number of sensors which gives information on the train positions. To avoid the practical problems with a real model railroad, we use a microcomputer (HCS12) to simulate the model railroad. This microcomputer system is called the train simulator. The picture of the model railroad is displayed in an X-window on the Linux work station. The communication between the simulator and the workstation is via a serial port. The model railroad is controlled from another microprocessor (MC68340) which we call the control computer. The control computer communicates with the train simulator using a serial link. This link is used to read sensor messages from the simulator and to send messages to the simulator to drive the trains and set the exchanges. A serial link between the control computer and the Linux workstaton is used to download the program to the control computer.


The railroad consists of a short track, a number of trains, exchanges and sensors with the following properties:

- Each train can drive forward or backward with different speeds.
- Each exchange can be set in two positions.
- The sensors that are located along the track signals when a train passes. Every sensor sends a message at both front end and back end of a train passage.
- The train speed and the state of the exchanges can be controlled by messages sent to the train simulator serial port. It is also possible to deactivate the sensors so that they do not react at all.

The assignment is to write the program for the control computer. The requirements are that two trains shall be able to share the railroad in a controlled way (that is without any accidents happening). The traditional solution to this type of problems is to use C or assembly language combined with interrupt handling. The synchronisation difficulties in these problems often lead to complicated solutions. We will see how elegant this problem can be solved using concurrent processes in Ada.

## 1.2 Train simulator overview

The train simulator is implemented on a HCS12 microprocessor card. The control computer is a Motorola 68340 microcontroller card and is connected to the simulator using an RS232 serial link. In order to drive the trains and set the exchanges, commands are sent to the simulator on the serial link. Signals from the sensors are sent by the simulator in the other direction on the serial link. The control computer is also connected to a Linux workstation used for program development. The simulator is also connected to the Linux workstation and an X-window is used to present the simulated railroad.



**Figure 2: Train simulator organisation**

The simulator and control microcomputers are mounted in a single box. The train simulator program is stored in FLASH memory. The simulator program starts automatically at power up, and can be restarted by pressing reset at the microcomputer box *or* by writing 'q' in the simulator window at Linux. The control computer contains a simple monitor **db68** that makes it possible to communicate with the Linux workstation and to download programs to the microcomputer.

### 1.3 Train simulator commands

This and the following section give a description of the commands that can be sent between the control computer and the simulator and the errors that can occur.

*Commands* can be of four types:

**Configure** This command restarts the train simulator. Trains, exchanges and sensors will “momentarily” be set to their initial positions (one of the few occasions there the model surpasses reality in performance). The command makes it possible to choose between a few different configurations.

**Set exchange** Set an exchange in the specified position.

**Activate sensor** The specified sensor is activated or deactivated.

**Set speed** The speed for the specified train is set to specified value.

The syntax of the configure command allows for 8 different configurations, each with a maximum of 16 exchanges, 16 sensors and 8 trains with a maximum of four speeds. Currently only four configurations are implemented. These configurations are described below.

A command is always a group of eight bits transported over the serial link. This will be further explained below. Commands have a type field (the two least significant bits) used for a command *type code*. The other six bits have different meaning dependent of the type code.

Command codes								
MSB	Bit number						LSB	Command type
7	6	5	4	3	2	1	0	
Value field						Type field		
0	Log	Rec.	C-number			0	0	Configure
0	Off	E-number				0	1	Set exchange
0	Active	S-number				1	0	Activate sensor
Rev	Speed		T-number			1	1	Set speed

The simulator interprets bits or bit fields in a command as follows:

**Log** A flag that specifies that activities shall be logged in the simulator window Simplifies debugging of the program. Set this bit to ‘1’ if you want the simulator to print out the received commands, set this bit to ‘0’ if you want to suppress this action.

**Rec** A flag that specifies that receipts shall be sent or not. Set this bit to ‘1’ if you want the simulator to acknowledge a command, set this bit to ‘0’ if you don’t want any acknowledges.

**C-number** Specifies which track configuration you desire. The field should contain a binary number (0-7). NOTE: Some of these numbers are not valid since they not correspond to an implemented configuration (see below).

**Off** Specifies if an exchange shall be set for turnoff or thoroughfare. Set

	this bit to '1' if turnoff is desired, set this bit to '0' if thoroughfare is desired.
E-number	Specifies which exchange to set. This should be a binary number ranging from 0 to 15.
Active	Specifies if a sensor shall be activated (set this bit to '1') or deactivated (set this bit to '0').
S-number	Specifies which sensor to activate (0-15).
Rev	Specifies if a train shall be driven forward (0) or backward (1).
Speed	the wanted speed for a train, 0 = stopped, 3 = maximum speed.
T-number	Specifies which train shall be controlled.

#### 1.4 Train simulator messages

The simulator sends notification messages to the control computer upon the following events:

Receipt	The latest command of the specified type has been completed or alternatively rejected for some reason
Passage	A sensor reacts when a train arrives to or leaves the place where the sensor is located.
Catastrophe	A train has collided, deranged or reversed. When a catastrophe is reported the simulator has to be reconfigured.

The simulator recognizes the following “catastrophic” conditions:

Collision	A train may not be driven against another train or into a stop block.
Deranging	A train may not be driven into an exchange set in the wrong position nor can an exchange be repositioned while a train is passing.
Reversing	The direction of movement cannot be changed while a train is moving. To prevent a catastrophe the train first have to be stopped.
Addressing	A command has been given that references a component (train, exchange, sensor) that do not exist in the current configuration

Messages returned from the simulator are encoded as follows:

Coding of simulator messages								
MSB	Bit number						LSB	Message type
7	6	5	4	3	2	1	0	
Value field						Type field		
0	0	0	Error	Type		0	0	
0	Start	S-number				0	1	Sensor signal
Rev	Derang	Coll	T-number			1	0	Catastrophe

Note that the type field is importanta for interpretation of the message. The general meanings of codes in the “value” field are explained as follows:

Error	Specifies that a command have been completed (0) or rejected (1) as the specified configuration, exchange, train or sensor cannot be addressed.
Type	Specifies the type for the message being acknowledged (see coding of commands).
Start	Specifies that a sensor has reacted at the beginning (1) or end (0) of a train.
S-number	specifies which sensor has reacted.
Rev	Specifies that direction of movement was reversed while the train was moving (1).
Derang	Specifies deranging (1).
Coll	Specifies collision (1).
T-number	Specifies which train has been hit by catastrophe.


### 1.5 Train simulator configurations

While the C-number in a configuration command allows any value, 0-7, there are actually only four configurations that are valid (0-3). The following four configurations are thus accepted:




**Figure 3: Configuration ‘0’**

The configuration shown in Figure 3 is intended for simple basic exercises such as to start and stop a train. The rails are represented with strait lines, and the end of a railroad track is marked with 'I'. A train is represented by a series of 'o' with the train number interjected. The train in the figure moves to the right, when given a command to move forward.




**Figure 4: Configuration ‘1’**

Configuration ‘1’, shown in Figure 4, is intended for test of sensors. Sensors are marked by an arrow (^) with its number immediately to the right. There are 16 different sensors in the most advanced configuration. Numbers indicating sensors are in hexadecimal format, i.e. the first sensor is denoted ‘0’, the last sensor is denoted ‘F’. Note that a sensor pass results in a message sent from the simulator. I.e. you must have a working program capable to receive messages before you test this configuration.



**Figure 5: Configuration '2'**

Configuration '2', shown in Figure 5, can be used to test exchanges. All exchanges are shown in the turnoff position. The number of the exchange is shown above the movable part of the exchange.



**Figure 6: Configuration '3'**

Configuration '3', Figure 6 shall be used in the final assignment. All exchanges are shown in turnoff position. The intention is to get the two trains moving simultaneously without colliding.

## 2 Communicating with the simulator

A serial link is used for the communication with the simulator. The Motorola 68340 processor has two serial ports. Port A is used for communication with the Linux workstation and port B is used for communication with the train simulator.

### 2.1 Control and status registers

The serial module in the 68340 processor have close to ten control registers that have to be programmed with the correct bit pattern to get the circuit working in the intended way.

A proper initialization of those registers are programmed by calling the routine *Init\_port\_B* in the given package *traintypes*. You don't have to be further bothered by this but you do have to recognize that the registers that have to be explicitly handled by your program is a status register and a data register for sending and reading characters on port B.

These registers have the following addresses:

Short name	Description	Address
SRB	Status register port B	FFFFFF719
TBB	Data register for sending to port B	FFFFFF71B
RBB	Data register for receiving from port B	FFFFFF71B

All these registers have 8 bits. All bits in the data register are used why both sent and received characters consist of 8 bits. The bits in the status register are described in the attached manual pages (se "Appendix: Excerpt from MC68340 USER'S MANUAL"). Observe that the bits are numbered according to the *Little Endian* method (from right to left) in the manual. The Gnu Ada 95 compiler on the other hand uses the *Big Endian* method (from left to right) in a *record representation clause*.

A number of control registers are already defined in the package *traintypes*, but these are only used by the routine *init\_port\_B*. The registers mentioned above remains to be defined as part of your assignment.

### 2.2 Sending commands to the simulator

Sending commands to the simulator is done by writing a character in the data register for port B (TBB). Beware that this is a direct communication with the underlying hardware. Before writing to the data register a check must be made that the circuit is prepared to receive a new character. This is done by reading the status register (SRB) and check that the correct bit is active.

### 2.3 Receiving messages from the simulator.

The reception of characters from the train simulator is interrupt driven. Interrupt routines in Ada 95 is programmed using protected objects. To connect an interrupt handler with its interrupt vector, the routine *attach\_handler* in the package *Ada.interrupts* is used. Alternatively the *Pragma attach\_handler* can be used. The interrupt vector to be used is defined in the package *Ada.interrupts.Names* and is called *PORTBINT*. Finally the serial module in the processor must be ordered to use this interrupt vector. This is done by the




routine `init_port_B`. The package `traintypes` includes a constant declaration for the interrupt vector, named `ivector`. It is a good idea to use this constant in the call of `attach_handler`.

The ceiling priority of the protected object containing the interrupt handler *should be set* to 104 using `pragma interrupt_priority`. This corresponds to the hardware priority 4, which is set for the serial module by `init_port_B`.

NOTE that it is crucial to get a working module for both output (sending commands) and inputs (receiving commands) otherwise your assignments 2, 3 and final cannot be accomplished.

## 2.4 Control computer memory space



**Figure 6: Memory usage in the control computer**

## 3 Assignment 1

### 3.1 Resource handler

The first assignment is to write a resource handler for allocation of the single tracks. This assignment does not use the microcomputer system and is developed on a native Ada 95 compiler on either Linux or a Windows PC. However the resource handler shall be written so that it can be included in the final train program without changes. For this reason the program is structured as an Ada package and a simple main program for testing purposes. Skeleton files for the assignment are given in the directory:

```
../../lib/lab1
```

at the Linux lab accounts. They are also available at the course homepage as:

Assignment1.zip.

The directory (this zip-file) contains the following files

```
resource.ads  
resource.adb  
traintypes.ads  
retest.adb
```

Start by creating a directory *lab1* using the command: `mkdir lab1`. Copy the given files to this directory with the command: `cp ../../lib/lab1/* lab1`

The file `resource.ads` is the complete package specification for the resource handler. It is demanded that this specification remains unchanged. The file `resource.adb` is a skeleton body for the resource handler. The major part of the assignment is to complete this file. The file `retest.adb` is the main program used to test that the resource handler is working correctly. This program is only a skeleton that has to be completed. The file `traintypes.ads` only contains the type definition for a track. This file should not be changed.

The program can be compiled with the command: `gnatmake retest.adb` and then executed by the command: `./retest`

The test program should test both correct and incorrect usage of the resource handler. It is however allowed to make temporary changes to test certain errors, for example that the same track cannot be allocated another time while it is still in use.

There is no reporting needed for this assignment. Continue with assignment 2 when you have a working resource handler.

## 4 Assignment 2

In this assignment the Gnu Ada95 cross compiler is used to develop a control program for the train simulator that can be downloaded to and executed at the control microcomputer. Observe that this compiler is only available at the Linux machines in the Computer Engineering lab.

Start by creating a new directory *lab2* and copy the given files to this directory with the command: `cp ../../lib/lab2/* lab2`.

Directory *lab2* should now contain the files `traintypes.ads`, `command.ads`, `command.adb` and `main.adb`. The file `traintypes.ads` contains type definitions for communication with the train simulator. The file `command.ads` specifies the interface to low level communication routines. This file is complete and may not be changed. The file `command.adb` contains the body for the low level communication routines and also the routine `init_port_B`. This file is incomplete and has to be completed. The file `main.adb` contains a skeleton main program that has to be completed. In the final solution the files `resource.ads` and `resource.adb` from *lab1* should also be copied here.

The files can be separately compiled with the command:

```
gada68 name.adb
```

The object files can then be linked together with the command:

```
gbind68 main
```

Now you should have an executable program named `main.x`. Now start the terminal emulator `68term` in a local X-window and download the file `main.x` to the 68340 microcomputer (see “Gnu Ada95 Cross Compiler for MC6xx0” for an instruction on how to do downloading). When the program is downloaded it can be started by giving the command:

```
go 3000
```

When all files needed by the program are written it is best to do recompilations with the command `gnatmake68 main`. This program performs all needed recompilations and then executes the linker. To get shorter load time it is recommended to use the command `gnatmake68f` instead of `gnatmake68`. This command links against routines that are preinstalled in the flash memory on the 68340 microcomputer.

The train simulator executes on a HCS12 microprocessor connected to the Linux workstation with a serial link. In order to start the train simulator, first open an extra X-window and give the command `68termB`. This is the same program as `68term` with the exception that it communicates on the serial port connected to the train simulator. If the train simulator does not start automatically, press the reset button at the microcomputer box. This will reset both the train simulator and the control microcomputer. The train simulator can also be restarted by writing ‘q’ (only the letter) when positioned in the simulator window. When the train simulator starts it gives the printout “READY FOR CONFIGURATION” in the X-window.

### 4.1 Testing commands to the simulator

Start by writing a simple test program that configures the simulator as *configuration 0* and *starts the train*. The train need not to be stopped, it is ok that it collides with the stop block.

Next step is to control the exchanges. Use *configuration 2* to verify that your program can set the exchanges in a desired position.

## 4.2 Monitoring messages from the simulator

Rewrite the program so that the passage of a sensor can be detected. To do this the communication routines in package *command.adb* have to be completed. For this step (and the future steps) configuration 3 can be used.

## 5 The final assignment

*Configuration 3* shall be used in the final assignment.

Program the body of *task type train* to allow the train to drive forward and backward at the track. Use the package *resource* from lab1 to allocate the single tracks. The exchanges connected to a single track should be set in correct position before the single track is entered. It is allowed to use the train number to select which double track to use. Other criteria such as the direction of the train may also be used. The direction of the train should change only when an endpoint is reached. The train should be able to drive at speed 3.

The *train task* should be written in a general way so that it can be used for both trains with only a minimum of parameterization based on train number. Only activate one train in this step, but test with both train numbers.

If the *train task* have been carefully written it should now be possible to get both trains running simultaneously just by activating both trains. If there are some problems you have to correct them.

The trains shall start from the endpoints and move against each other. When a train reaches an endpoint it should turn back. The trains shall continue to run for ever without any accidents happening. Both trains shall be in movement at the same time.

### 5.1 Requirements on the program

- The resource handler shall use Ada 95 protected objects.
- Interrupt handling shall be used to receive messages from the simulator.
- A general train task shall be implemented to drive the trains.
- Both trains shall be able to run at speed 3.

### 5.2 Practical hints

You should structure the problem by drawing an access graph. The access graph shall show the call structure between the different tasks and packages. An access graph is required in your final documentation

Wait for a receipt when a command has been sent to the simulator. This will guarantee that the simulator has read a command before a new command is sent. You will probably not be able to solve this assignment unless you do so.

Tasks start in an arbitrary order. They have to be synchronized at start.

Speed 0 forward is not the same as speed 0 backward.

Trains have inertia. At the end stations the trains have to wait for 10 seconds after the speed is set to 0 before they can be started in the other direction.

Recommendation: Do not call procedures in other protected objects from an interrupt handler. If despite of this recommendation this is done, the called protected object must be set to interrupt priority.

It is not allowed to call an entry (or any potentially blocking operation) from a protected object when the real time annex is used.

Use `gnatmake68f`. This gives much shorter download times than `gnatmake68`.

## 6 Criterias to pass

A working program shall be demonstrated for an instructor during a lab session and the same program shall also be documented in a written report submitted to the instructor in due time (see course homepage). Only the final solution of source code needs to be submitted along with appropriate documentation.

### 6.1 Reporting and documentation

At the demonstration each of the group members shall be able to explain all parts of the program. A preliminary version of the report should also be shown for the instructor at the demonstration.

### 6.2 Instructions for report writing

The report shall include the following parts:

- Program description
- Access graph
- Program listing

The program description shall contain a short description of the problem and a detailed description of the packages, tasks and protected objects that implements the program. The report should be 3-4 pages and well structured. The program listings shall have file name and page number at every page (use `a2ps`). The report may be written in Swedish or English.

The lab report should be submitted before the deadline specified at the course homepage. If the report is not approved it is returned and have to be resubmitted after corrections. The last date for approval is given at the course home page.

**APPENDIX A: Excerpt from MC68340 USER'S MANUAL**

NOTE: The entire chapter 7, detailing the UART device, from this handbook is available at the course homepage.

7.4.1.5 STATUS REGISTER (SR). The SR indicates the status of the characters in the FIFO and the status of the channel transmitter and receiver. This register can only be read when the serial module is enabled (i.e., the STP bit in the MCR is cleared).

SRA, SRB				\$711, \$719			
7	6	5	4	3	2	1	0
RB	FE	PE	OE	TxEMP	TxRDY	FFULL	RxRDY
RESET:							
0	0	0	0	0	0	0	0
Read Only				Supervisor/User			

**RB-Received Break**

1 = An all-zero character of the programmed length has been received without a stop bit. The RB bit is only valid when the RxRDY bit is set. Only a single FIFO position is occupied when a break is received. Further entries to the FIFO are inhibited until the channel RxDx returns to the high state for at least one-half bit time, which is equal to two successive edges of the internal or external 1x clock or 16 successive edges of the external 16x clock.

The received break circuit detects breaks that originate in the middle of a received character. However, if a break begins in the middle of a character, it must persist until the end of the next detected character time.

0 = No break has been received.

**FE-Framing Error**

1 = A stop bit was not detected when the corresponding data character in the FIFO was received. The stop-bit check is made in the middle of the first stop-bit position. The bit is valid only when the RxRDY bit is set.

0 = No framing error has occurred.

**PE-Parity Error**

1 = When the with parity or force parity mode is programmed in the MR1, the corresponding character in the FIFO was received with incorrect parity. When the multidrop mode is programmed, this bit stores the received A/D bit. This bit is valid only when the RxRDY bit is set.

0 = No parity error has occurred.

**OE-Overrun Error**

1 = One or more characters in the received data stream have been lost. This bit is set upon receipt of a new character when the FIFO is full and a character is already in the shift register waiting for an empty FIFO position. When this occurs, the character in the receiver shift

register and its break detect, framing error status, and parity error, if any, are lost. This bit is cleared by the reset error status command in the CR.

0 = No overrun has occurred.

#### **TxEMP-Transmitter Empty**

1 = The channel transmitter has underrun (both the transmitter holding register and transmitter shift registers are empty). This bit is set after transmission of the last stop bit of a character if there are no characters in the transmitter holding register awaiting transmission.

0 = The transmitter buffer is not empty. The transmitter holding register is loaded by the CPU32, or the transmitter is disabled. The transmitter is enabled/disabled by programming the TCx bits in the CR.

#### **TxRDY-Transmitter Ready**

This bit is duplicated in the ISR; bit 0 for channel A and bit 4 for channel B.

1 = The transmitter holding register is empty and ready to be loaded with a character. This bit is set when the character is transferred to the transmitter shift register. This bit is also set when the transmitter is first enabled. Characters loaded into the transmitter holding register while the transmitter is disabled are not transmitted and are lost.

0 = The transmitter holding register was loaded by the CPU32, or the transmitter is disabled.

#### **FFULL-FIFO Full**

1 = A character was transferred from the receiver shift register to the receiver FIFO and the transfer caused the FIFO to become full (all three FIFO holding register positions are occupied).

0 = The CPU32 has read the receiver buffer and one or more FIFO positions are available. Note that if there is a character in the receiver shift register because the FIFO is full, this character will be moved into the FIFO when a position is available, and the FIFO will remain full.

#### **RxRD-Receiver Ready**

1 = A character has been received and is waiting in the FIFO to be read by the CPU32. This bit is set when a character is transferred from the receiver shift register to the FIFO.

0 = The CPU32 has read the receiver buffer, and no characters remain in the FIFO after this read.

## APPENDIX B:

The following source code is available from the course home page. This appendix is for your reference.

```
-- traintypes.ads
-- Type declarations for the Ada95 train lab assignment
-- 06-09-27  Arne Dahlberg

with calendar, system, system.storage_elements;
with Ada.Interrupts.Names;
use calendar, system, system.storage_elements;
package traintypes is

-- Miscellaneous types
-- 8-bit type for general use
subtype byte is integer range 0..255;

-- Type for accessing hardware registers
type bits is range 0..255;
for bits'size use 8;

-- Type declarations for commands to the simulator

type command_type is (CONF, SWITCH, SENS, SPEED);
for command_type use (CONF => 0, SWITCH => 1, SENS => 2, SPEED => 3);

subtype conf_nr_type is integer range 0..7;
subtype train_nr_type is integer range 0..7;
subtype switch_nr_type is integer range 0..15;
subtype sens_nr_type is integer range 0..15;
subtype speed_type is integer range 0..3;

type yesno_type is (NO, YES);
for yesno_type use (NO => 0, YES => 1);

type direct_type is (STRAIT, OFF);
for direct_type use (STRAIT => 0, OFF=> 1);

type drive_dir_type is (FORW, BACKW);
for drive_dir_type use (FORW => 0, BACKW => 1);

type conf_cmd_type is
record
  ctype : command_type;
  conf_nr : conf_nr_type;
  ack : yesno_type;
  log : yesno_type;
  unused : yesno_type := NO;
end record;

for conf_cmd_type use
record
  ctype at 0 range 6..7;
  conf_nr at 0 range 3..5;
  ack at 0 range 2..2;
  log at 0 range 1..1;
  unused at 0 range 0..0;
end record;
for conf_cmd_type'size use 8;

type switch_cmd_type is
record
  ctype : command_type;
  switch_nr : switch_nr_type;
  direct : direct_type;
  unused : yesno_type := NO;
end record;
```



```

for switch_cmd_type use
  record
    ctype at 0 range 6..7;
    switch_nr at 0 range 2..5;
    direct at 0 range 1..1;
    unused at 0 range 0..0;
  end record;
for switch_cmd_type'size use 8;

type sens_cmd_type is
  record
    ctype : command_type;
    sens_nr : sens_nr_type;
    active : yesno_type;
    unused : yesno_type := NO;
  end record;

for sens_cmd_type use
  record
    ctype at 0 range 6..7;
    sens_nr at 0 range 2..5;
    active at 0 range 1..1;
    unused at 0 range 0..0;
  end record;
for sens_cmd_type'size use 8;

type speed_cmd_type is
  record
    ctype : command_type;
    train_nr : train_nr_type;
    speed : speed_type;
    drive_dir: drive_dir_type;
  end record;

for speed_cmd_type use
  record
    ctype at 0 range 6..7;
    train_nr at 0 range 3..5;
    speed at 0 range 1..2;
    drive_dir at 0 range 0..0;
  end record;
for speed_cmd_type'size use 8;

-- Control word declarations for serial port B

ILR_address : constant System.address := to_address(16#FFFFFF704#);
IVR_address : constant System.address := to_address(16#FFFFFF705#);
ISR_address : constant System.address := to_address(16#FFFFFF715#);
IER_address : constant System.address := to_address(16#FFFFFF715#);
MR1B_address : constant System.address := to_address(16#FFFFFF718#);
MR2B_address : constant System.address := to_address(16#FFFFFF721#);
CSRB_address : constant System.address := to_address(16#FFFFFF719#);
CRB_address : constant System.address := to_address(16#FFFFFF71A#);

D_ILR : bits;
for D_ILR'address use ILR_address;
D_IVR : bits;
for D_IVR'address use IVR_address;
D_ISR : bits;
for D_ISR'address use ISR_address;
D_IER : bits;
for D_IER'address use IER_address;
D_MR1B : bits;
for D_MR1B'address use MR1B_address;
D_MR2B : bits;
for D_MR2B'address use MR2B_address;
D_CSRB : bits;
for D_CSRB'address use CSRB_address;
D_CRB : bits;
for D_CRB'address use CRB_address;

```

```
-- Init definitions for Port B

    ivector : constant := Ada.Interrupts.Names.PORTBINT;
    cmd_reset_receiver : bits := bits(16#20#);
    cmd_reset_transmitter : bits := bits(16#30#);
    cmd_reset_errorstatus : bits := bits(16#40#);
    cmd_reset_break : bits := bits(16#50#);
    rec_irq_enable: bits := bits(16#24#); -- rec int. B + brk int. A enable
    cmd_enable_receiver : bits := bits(16#01#);
    cmd_enable_transmitter : bits := bits(16#04#);
    MR1B_init : constant bits := bits(16#13#); -- 8 bits, no parity
    MR2B_init : constant bits := bits(16#07#); -- normal, 1 stop bit
    CSRB_init : constant bits := bits(16#BB#); -- 9600 baud, Rx and Tx
    ILEVEL : bits := bits(16#04#); -- Interrupt level port A and portB !!
    VECTOR : bits := bits(ivector); -- Interrupt vector port A and port B !!

-- Type declarations for messages from simulator

    --Write your own declarations for this part

end traintypes;
```